

## View and control your Zip NVR system from your Android device

- FREE download
- Remote viewing of your CCTV on an Android phone or tablet
- Live full screen control of PTZ cameras
- Trigger relays remotely
- Playback recordings from a DVR and save video clippings
- Record footage locally to your device

The Zip CCTV Android app provides remote viewing, PTZ control, relay control and even quad viewing of a camera recording all on to the device. Use your device to monitor your CCTV system on the move, record footage and even control relay items like gates, barriers etc. A great extra for your Zip CCTV system!

## System Requirements

<b>Android Version</b>	Supports Android 3.0 or later*
<b>Compatible Devices</b>	Android Phone / Android Tablet
<b>Space Required</b>	Installation requires approximately 12MB, additional space is required for long term storage of images and video snippets
<b>Internet Connection</b>	Wifi or mobile internet connection required for live view and remote access
<b>Bandwidth</b>	For best results we recommend setting the NVR's substream to CIF @ 12fps which requires 256kb/s per channel in live view**

\*Android 7.0 or later recommend

\*\*on high speed connections the stream quality and frame rate can be increased.

## Licensing

<b>Licences</b>	Unlimited
<b>Support Period</b>	3 Months ticket based support*
<b>URL</b>	<a href="https://play.google.com/store/apps/details?id=com.zip.client">https://play.google.com/store/apps/details?id=com.zip.client</a>

\*Downloads within the support period are available via your personalised Control Panel.



## FAQs

Can I remotely view and control my Zip CCTV camera system over the internet using my android device?

### Answer

The FREE Zip CCTV android app available in the Google Play Store allows you to view your cameras and control your NVR from anywhere in the world. Just search for "ZipVision" on the Play Store.

You'll need to make sure your Zip NVR or DVR has been networked and setup for remote viewing then simply enter its information and you're good to go.

What internet speed do I need stream live video from a Zip NVR or DVR?

### Answer

The quality of image you can stream depends on your available bandwidth and the bit rate of the live images you are trying to view. For best results we recommend setting the DVR/NVR's sub-stream to CIF @ 12fps which requires 256kb/s per channel in live view.

If you have a high speed internet connection you can increase the stream quality and frame rate to suit your needs. A 720p 12fps image for example would require roughly 2MB/s per channel.

## Quick Links

Free Download - Zip Android App

<https://play.google.com/store/apps/details?id=com.zip.client>



Free Download - Zip iOS App


<https://apps.apple.com/gb/app/zipvision/id1297896909>



Zip Enduser Site - Information & Support

<http://zipnvr.com/>





Zip NVR Range - Quick Comparison

<http://zipnvr.com/NVR-Range.html>



Zip DVR Range - Quick Comparison

<http://zipnvr.com/DVR-Range.html>

